mySewnet Embroidery Software
Level: Platinum

Digitizing Wizard

Create your own custom embroidery designs.
- Start with your own picture and edit in an easy way.

|		
	Open a blank canvas and choose the 360x260mm Hoop Rotated	
	Go to the create tab and click Digitizing	
	This will show a pop-up and open the Digitizing module in a separate window.	

2	It will also open the Express Design Wizard and the different options you can choose to start digitize.	
	Create a standard embroidery from a picture, using satin and fill areas for color areas in the picture. Outlines will be created using running stitch or Satin.	
	Create an embroidery by tracing outlines in the picture. Select from light or heavy running stitch, or constant width satin.	
	Create running stitch, motif, satin line or appliqué around enclosed aread in the picture.	
	Load or draw an image, to use as a guide for a new design.	
	Load an existing design outline to be edited or completed.	

	Start a completely new design with no background image.	
	Choose create Express Embroidery	Create Express Embroidery
	Choose a monochrome picture, just to try the tools. Click Next	
	In the next window you can crop the picture. Click Next	

	In the next window, choose Design Size. You can either Fit Design to Hoop or Enter Design Size Only the chosen option in the top of the window will be possible to edit in Hoop size or Design Size.	

5		**Choose Thread Colors** Zoom 🔍+ 🔍− ⊡ 1:1 Color Selection 🎨 19 ▲▼ Apply Reset Change All To Robison-Anton Rayon 40 ⌄ Robison-Anton Rayon 40 2343 E Robison-Anton Rayon 40 2343 E Robison-Anton Rayon 40 2297 S Robison-Anton Rayon 40 2574 A Robison-Anton Rayon 40 2574 A Robison-Anton Rayon 40 2322 N Robison-Anton Rayon 40 2322 N Robison-Anton Rayon 40 2322 N Robison-Anton Rayon 40 2457 G Robison-Anton Rayon 40 2457 G Move Up Move Down Change Thread Pick Delete Delete All
		Color Selection 🎨 10 ▲▼ Apply Reset Change All To Robison-Anton Rayon 40 ⌄
		Background Color ☑ Automatically Remove Background Color ◉ Remove main background only ○ Remove all background color areas 🖊 Picture Options

	Now you have the possibility to change the points around the areas if it didn't turn out as you expected.	
	You can also change the angle of the fill area to fit the design better.	
	Or right click to change to a different fill pattern.	
	To save the design click on File and Save As. This will save a .edo file that is fully editable again if you want to continue working with it.	

	If you want a different format you use the Export instead.	<table><tr><td>(←)</td></tr><tr><td>Welcome</td></tr><tr><td>New Window</td></tr><tr><td>Open</td></tr><tr><td>Insert</td></tr><tr><td>Save</td></tr><tr><td>Save As</td></tr><tr><td>Export</td></tr></table>	
	Here you will get a list of all available formats and you can choose the format you need for your embroidery machine.	Husqvarna Viking / Pfaff (.vp4) Husqvarna Viking / Pfaff (.vp4) Husqvarna Viking / Pfaff (.vp3) Brother / Baby Lock / Bernina (.pes) Brother / Baby Lock / Bernina (.pec) Compucon / Singer (.xxx) Husqvarna Viking Designer I (.shv) Husqvarna Viking / Pfaff (.vip) Husqvarna (.hus) Janome / Singer (.jef) Janome (.sew) Melco Expanded (.exp) Pfaff (.pcs) Tajima (.dst) Toyota (.10o)	

7